

# EITRE<sup>®</sup> 3 / 6 / 8

NIL FOR RESEARCH & DEVELOPMENT

---



## HIGHLIGHTS

- Versatile and flexible semi-automatic tool
- Thin and uniform residual layer
- Capable of performing both UV- and Thermal NIL processes
- Highly customizable through tool options

# EITRE® 3 / 6 / 8

## GENERAL INFORMATION

### Key Features

- The EITRE® Nano Imprint Lithography (NIL) systems offer a semi-automated and affordable lithography solution, allowing pattern replication in the micro- and nanometer range.
- The EITRE® systems are particularly versatile because of the multiple imprint process capabilities and the wide range of configuration possibilities.
- An easy-to-use semi-automatic solution with a user-friendly interface.
- The embedded SoftPress® technology ensures excellent residual layer thickness control across the entire imprint area, enabling an accurate pattern transfer and easy down stream process development.
- The flexibility of the systems allows for a variety of imprint processes to be used, such as hot embossing, thermal NIL, UV NIL and Obducat's unique Simultaneous Thermal and UV (STU®) process.
- The EITRE® systems are suitable for research and development within application areas such as solid-state lighting, micro optical and photonic components, bio-medical and life science devices, lab-on-chip, MEMS/NEMS and semiconductors.
- Full area imprint
- Designed according to European safety regulations and CE Mark



Intermediate Polymer Stamp, IPS®



Close-up of the EITRE® Imprint unit

## Obducat's NIL Process Technologies

### IPS® - Intermediate Polymer Stamp

The patented IPS® technology is based on making a replication of the master stamp into a soft Intermediate Polymer Stamp (IPS®). The IPS® is then used in a second imprint step to transfer the structures onto the target substrate.

The IPS® enables contamination control, increases the master stamp lifetime and makes the imprint process less sensitive to substrate contaminations and surface roughness.

### SoftPress®

With Obducat's patented SoftPress® technology, the imprint pressure is applied using compressed gas, ensuring pressure uniformity over the entire imprint area. This allows the stamp or IPS® to conform to the substrate, eliminating negative effects from thickness variations, bow or waviness. SoftPress® enables thin and uniform residual layer across the substrate, which is critical for enabling high-resolution imprinting and pattern transfer fidelity.

### STU® - Simultaneous Thermal and UV

The patented STU® technology combines, in one imprint sequence, the simultaneous use of thermal- and UV based imprint processes. The STU® process allows for increased polymer flow rate giving a shorter process time as well as enabling improved material compatibility and thereby a wider selection of workable imprint materials.

# EITRE<sup>®</sup> 3 / 6 / 8

## TECHNICAL DATA

### TOOL CONFIGURATIONS

The standard configuration of the EITRE<sup>®</sup> Systems includes Imprint Module based on the proprietary SoftPress<sup>®</sup> technology, Computer Controlled User Interface, Manual Loading System and SoftPress<sup>®</sup> Technology License for Non-Commercial R&D.

	<b>EITRE<sup>®</sup> 3</b>	<b>EITRE<sup>®</sup> 6</b>	<b>EITRE<sup>®</sup> 8</b>
<b>Substrate Size</b>	≤ 78 mm Ø	≤ 152 mm Ø	≤ 200 mm square
<b>Imprint Pressure (minimum)</b>	6-8 bar (depending inlet pressure on CA)	6 - 8 bar (depending inlet pressure on CA)	6 - 8 bar (depending inlet pressure on CA)
<b>Imprint Pressure (maximum)</b>	70 bar	80 bar	≤ 50 bar
<b>Imprint Temperature (minimum)</b>	Ambient temperature	Ambient temperature	Ambient temperature
<b>Imprint Temperature (maximum)</b>	250°C (200°C with UV Module)	250°C (200°C with UV Module)	250°C (200°C with UV Module)
<b>Imprint Temperature Setting Accuracy</b>	± 2 deg	± 2 deg	± 2 deg

### TOOL OPTIONS

	<b>EITRE<sup>®</sup> 3</b>	<b>EITRE<sup>®</sup> 6</b>	<b>EITRE<sup>®</sup> 8</b>
<b>UV imprint</b>	Option	Option	Option
<b>STU<sup>®</sup> technology license for R&amp;D</b>	Option	Option	Option
<b>IPS<sup>®</sup> technology license for R&amp;D</b>	Option	Option	Option
<b>Water cooling</b>	Option	Option	Standard
<b>Optical alignment</b>	N/A	Option	Option
<b>Low pressure Module</b>	Option	Option	Option

### FACILITY REQUIREMENTS

	<b>EITRE<sup>®</sup> 3</b>	<b>EITRE<sup>®</sup> 6</b>	<b>EITRE<sup>®</sup> 8</b>
<b>Clean-room compability</b>	Class 100	Class 100	Class 100
<b>Room Temperature</b>	18-32°C	18-32°C	18-32°C
<b>Relatively Humidity</b>	40 - 65 %	40 - 65 %	40 - 65 %
<b>Power</b>	220-240 VAC, 1 phase, grounded, pre-fused to 16A, 50/60 Hz, 3 kVA	400 VAC, 3 phase, grounded, pre-fused to 32A, 50/60 Hz, 16 kVA	400 VAC, 3 phase, grounded, pre-fused to 32A, 50/60 Hz, 16 kVA
<b>Compressed Air</b>	6 - 8 bar, 30 l / min	6 - 8 bar, 40 l / min	6 - 8 bar, 40 l / min
<b>Exhaust Flow</b>	1000 - 2000 l / min	1500 - 3000 l / min	1500 - 3000 l / min

### SYSTEM DIMENSIONS

	<b>EITRE<sup>®</sup> 3</b>	<b>EITRE<sup>®</sup> 6</b>	<b>EITRE<sup>®</sup> 8</b>
<b>Dimensions (L x W x H)</b>	80 x 60 x 180 cm*	100 x 75 x 180 cm*	100 x 75 x 180 cm*
<b>Weight</b>	Approx. 250 kg*	Approx. 1000 kg*	Approx. 1000 kg*

\*not including auxiliary equipment



# CONTACT US

[www.obducat.com](http://www.obducat.com)



o b d u c a t

## **Obducat Technologies AB**

Scheelevägen 2  
22363 Lund  
Sweden  
Phone: +46 46 10 16 00

## **Obducat Europe GmbH**

Robert-Gerwig-Str. 9  
78315 Radolfzell  
Germany  
Phone: +49 7732 97 898-0  
Fax: +49 7732 97 898-99

## **Obducat USA Inc.**

851 Burlway Rd, #605  
Burlingame, Ca 94010  
USA  
Phone: +1 510 871 0041  
Phone: +1 619 565 4844

**Visit our website for local  
sales offices  
[www.obducat.com](http://www.obducat.com)**

Made in Sweden. All rights reserved. This folder is subject to change without prior notice. Illustrations, photos and specifications in this brochure are not legally binding. Pictures could show standard equipment plus options.